
6. APPLICATION EXAMPLES OF BASIC COMMANDS

Application #5: Filling/Draining Control Operation



• I/O Assignments


| Input | Device |
|-------|---------------------------|
| 00000 | Start Button (PB1) |
| 00001 | Stop Button (PB2) |
| 00002 | Reset Button (PB3) |
| 00005 | Upper Level Switch (TLB1) |
| 00006 | Lower Level Switch (TLB2) |

| Output | Device |
|--------|--------------------------|
| 01000 | Water Supply Valve (MV1) |
| 01001 | Drain Valve (MV2) |
| 01002 | Stirring Motor (M) |
| 01004 | End Indicator |
| 01005 | Buzzer |

• Procedure

- 1. As the PB1 is pressed, MV1 opens and the water begins to fill the tank. At the same time, the stirring motor M starts operations.
- 2. When the water level passes TLB2 and reaches TLB1, the MV1 closes and the stirring motor stops.
- 3. Next, MV2 opens and starts draining the water. When the water levels drops below TLB2, MV2 closes.
- 4. When the cycle of operation has repeated four times, the operation END indicator illuminates, and the filling and draining operation will not restart even if PB1 is pressed.

6. APPLICATION EXAMPLES OF BASIC COMMANDS



6. APPLICATION EXAMPLES OF BASIC COMMANDS

